



# USER MANUAL

## FOR TECHMAN ROBOTS

v1.8.0

*Original Instructions*

# Contents

<b>1. Introduction</b> .....	<b>5</b>
1.1. Important Safety Notice.....	5
1.2. Scope of the Manual.....	5
1.2.1. 3FG15.....	5
1.2.2. Software and Firmware.....	5
1.2.2.1. Compute Box.....	5
1.3. Naming Convention.....	5
1.3.1. 3FG15.....	5
1.3.2. Compute Box/Eye Box.....	5
1.4. Copyright.....	6
<b>2. Safety</b> .....	<b>7</b>
2.1. Intended Use.....	7
2.2. General Safety Instructions.....	7
2.3. Risk Assessment.....	8
2.4. Environmental Safety.....	9
<b>3. HW Installation</b> .....	<b>10</b>
3.1. Overview.....	10
3.2. Robot Mount.....	10
3.2.1. Quick Changer Mounting.....	10
3.2.1.1. Quick Changer - Robot Side.....	10
3.2.1.2. 3FG15.....	10
3.2.2. Tools.....	11
3.2.2.1. 3FG15.....	11
3.3. Compute Box Mount.....	11
3.3.1. Optional - Clip-on Bracket.....	11
3.4. Wiring.....	11
3.4.1. Tool Data Cable.....	12
3.4.1.1. Cable to 3FG15.....	12
3.4.1.2. Cable to Compute Box.....	12
3.4.2. Ethernet Cable.....	13
3.4.3. Compute Box DIP Switch Settings.....	13
3.4.4. Power Supply: Compute Box.....	14
3.4.4.1. 3FG15.....	14
<b>4. SW Installation</b> .....	<b>15</b>
4.1. Robot Software Setup.....	15
4.1.1. Import Component.....	15
4.1.2. Set Robot Network Settings.....	17
4.1.3. Configure Gripper Buttons.....	18
4.1.4. Configuring Modbus TCP for the Components.....	19

<b>5. Operation.....</b>	<b>22</b>
5.1. Robot Operation Overview.....	22
5.2. 3FG15 Components.....	24
5.2.1. Gripper_OR_3FG_100_GRIP .....	24
5.2.2. Gripper_OR_3FG_100_RELEASE.....	26
5.2.3. Gripper_OR_3FG_100_CONFIG.....	26
<b>6. Additional Software Options.....</b>	<b>27</b>
6.1. Compute Box/Eye Box.....	27
6.1.1. Ethernet Interface Setup.....	27
6.1.2. Web Client.....	29
6.1.3. Web Client: Devices Menu.....	30
6.1.3.1. 3FG15.....	31
6.1.4. Web Client: Configuration Menu.....	34
6.1.5. Web Client: Update Menu.....	35
6.1.6. Web Client: Account Settings.....	37
<b>7. Hardware Specification.....</b>	<b>41</b>
7.1. Technical Sheets.....	41
7.1.1. 3FG15.....	41
7.1.2. Compute Box.....	47
7.1.2.1. With 1.5A Wall Adapter (36W).....	47
7.1.2.2. With 6.25A Wall Adapter (150W).....	48
7.1.2.3. Compute Box I/O interface.....	48
7.2. Mechanical Drawings.....	49
7.2.1. Mountings.....	49
7.2.1.1. Quick Changer - Robot Side.....	49
7.2.2. Tools.....	50
7.2.2.1. 3FG15.....	50
7.2.2.2. Compute Box.....	51
7.3. COG, TCP.....	52
7.3.1. 3FG15.....	52
<b>8. Maintenance.....</b>	<b>53</b>
8.1. 3FG15.....	53
<b>9. Troubleshooting.....</b>	<b>54</b>
9.1. Robot Has Not Obtained an IP Address.....	54
9.2. Error During Operation.....	54
<b>10. Warranties.....</b>	<b>55</b>
10.1. Patents.....	55
10.2. Product Warranty.....	55
10.3. Disclaimer.....	55

<b>11. Certifications.....</b>	<b>56</b>
11.1. EMC.....	57
11.2. Declaration of Incorporation.....	58
11.2.1. 3FG15.....	58

# 1. Introduction

## 1.1. Important Safety Notice



**DANGER:**

You must read, understand, and follow all safety information in this manual, and the robot manual and all associated equipment before initiating robot motion. Failure to comply with safety information could result in death or serious injury.

## 1.2. Scope of the Manual

The manual covers the following OnRobot products and their components:

### 1.2.1. 3FG15

Tool	Version
3FG15	v1

### 1.2.2. Software and Firmware

#### 1.2.2.1. Compute Box

The manual covers the following Compute Box software version:

Software	Version
Compute Box	v5.8.1



**NOTE:**

When the used Compute Box has lower software/firmware version, update the Compute Box. For detailed instructions, see [6.1.5. Web Client: Update Menu](#).

## 1.3. Naming Convention

### 1.3.1. 3FG15

The 3FG15 product sometimes will be called TFG as Three-Finger Gripper.

### 1.3.2. Compute Box/Eye Box

Eye Box and Compute Box are used interchangeably.

## 1.4. Copyright

---

The information contained herein is property of OnRobot A/S and shall not be reproduced in whole or in part without prior written approval of OnRobot A/S. The information herein is subject to change without notice and should not be construed as a commitment by OnRobot A/S. This manual is periodically reviewed and revised.

OnRobot A/S assumes no responsibility for any errors or omissions in this document.

Copyright © 2015–2021 by OnRobot A/S.

The OnRobot A/S logo is trademark of OnRobot A/S.

## 2. Safety

The robot integrators are responsible for ensuring that the applicable safety laws and regulations in the country concerned are observed and that any significant hazards in the complete robot application are eliminated. This includes, but is not limited to:

- Performing a risk assessment for the complete robot system
- Interfacing other machines and additional safety devices if defined by the risk assessment
- Setting up the appropriate safety settings in the robot software
- Ensuring that the user will not modify any safety measures
- Validating that the total robot system is designed and installed correctly
- Specifying instructions for use
- Marking the robot installation with relevant signs and contact information of the integrator
- Collecting all documentation in a technical file; including the risk assessment and this manual

### 2.1. Intended Use

---

OnRobot tools are intended to be used on collaborative robots and light industrial robots with different payloads depending on the end-of-arm tooling specifications. OnRobot tools are normally used in pick-and-place, palletizing, machine tending, assembly, quality testing and inspection and surface finishing applications.

The end-of-arm tooling should only operate under conditions noted in [7.1. Technical Sheets](#) section.

Any use or application deviating from intended use is deemed to be impermissible misuse. This includes, but is not limited to:

- Use in potentially explosive atmospheres
- Use in medical and life critical applications
- Use before performing a risk assessment
- Use outside the permissible operational conditions and specifications
- Use close to a human's head, face and eye area
- Use as a climbing aid

### 2.2. General Safety Instructions

---

Generally, all national regulations, legislations and laws in the country of installation must be observed. Integration and use of the product must be done in compliance with precautions in this manual. Particular attention must be paid to the following warnings:

**DANGER:**

You must read, understand, and follow all safety information in this manual, and the robot manual and all associated equipment before initiating robot motion. Failure to comply with safety information could result in death or serious injury.

The information in this manual does not cover designing, installing, and operating a complete robot application, nor does it cover other peripheral equipment that can influence the safety of the complete system. The complete system must be designed and installed in accordance with the safety requirements set forth in the standards and regulations of the country where the robot is installed.

Any safety information provided in this manual must not be construed as a warranty, by OnRobot A/S, that the robot application will not cause injury or damage, even if robot application complies with all safety instructions.

OnRobot A/S disclaims any and all liability if any of OnRobot tools tooling are damaged, changed or modified in any way. OnRobot A/S cannot be held responsible for any damages caused to any of OnRobot tools tooling, the robot, or any other equipment due to programming errors or malfunctioning of any of OnRobot tools.

**WARNING:**

OnRobot tools are not allowed to be exposed to condensing conditions when power is on or when connected to a robot. If condensing conditions appear during transport or storage, the product must be placed between 20 and 40 Celsius degrees for 24 hours before power is applied or before connected to a robot.

It is recommended that OnRobot tools are integrated in compliance with the following guides and standards:

- ISO 10218-2
- ISO 12100
- ISO/TR 20218-1
- ISO/TS 15066

## 2.3. Risk Assessment

---

The robot integrator must perform a risk assessment on the complete robot application. OnRobot tools are only components in a robot application and therefore they can be only safely operated if the integrator has considered the safety aspects of the whole application. OnRobot tools are designed with relatively smooth and round design with a limited amount of sharp edges and pinch points

In collaborative applications, the trajectory of the robot can play a significant safety role. The integrator must consider the angle of contact with a human body, e.g. orientate OnRobot tools and workpieces so that the contact surface in the direction of movement is as large as possible. It is recommended that the tool connectors are pointed in the direction opposite to the movement.



OnRobot A/S have identified the potential hazards listed below as significant hazards that must be considered by the integrator:

- Objects flying from OnRobot tools due to loss of grip
- Objects falling down from OnRobot tools due to loss of grip
- Injuries due to collisions between humans and workpieces, OnRobot tools tooling, robot or other obstacles
- Consequences due to loosen of bolts
- Consequences if OnRobot tools cable gets stuck to something
- Workpiece itself represents a hazard

## 2.4. Environmental Safety

---

OnRobot A/S products must be disposed of in accordance with the applicable national laws, regulations and standards.

The product is produced with restricted use of hazardous substances to protect the environment; as defined by the EU RoHS Directive 2011/65/EU. These substances include mercury, cadmium, lead, chromium VI, polybrominated biphenyls and polybrominated diphenyl ethers.

Observe national [registration](#) requirements for importers according to EU WEEE Directive 2012/19/EU.



## 3. HW Installation

### 3.1. Overview

For a successful installation the following steps will be required:

- Mount the components
- Setup the software


In the following sections, these installation steps will be described.

### 3.2. Robot Mount

1. Mount the robot-specific adapter (if applicable)
2. Mount any optional accessories
3. Mount the Quick Changer option
4. Mount the tool(s) (if applicable)

#### 3.2.1. Quick Changer Mounting

##### 3.2.1.1. Quick Changer - Robot Side



#### Quick Changer - Robot Side

1. M6x8mm (ISO14580 8.8)
2. Quick Changer (ISO 9409-1-50-4-M6)
3. Dowel pin Ø6x10 (ISO2338 h8)
4. Adapter/ Robot tool flange (ISO 9409-1-50-4-M6)


Use 10 Nm tightening torque.

##### 3.2.1.2. 3FG15

Tool	QC-R v2	QC-R v2-4.5 A
3FG15	✓	✓

### 3.2.2. Tools

#### 3.2.2.1. 3FG15



#### Step 1:

Move the tool close to the Quick Changer as illustrated.

The hook mechanism (rod and hook tongue) will keep the lower part locked once mounted.

#### Step 2:


Flip the tool until it is fully mated, and you hear a clicking sound.

To unmount the tool, press the aluminum button on the Quick Changer and repeat the steps in the reverse order.

## 3.3. Compute Box Mount

### 3.3.1. Optional - Clip-on Bracket

Optionally, fix the Compute Box to a surface using the provided Clip-on Brackets ( included only from 17th December 2020).



Do the following on both sides of the Compute Box:


1. Hook the Clip-on Bracket to the rail on the side of the Compute Box and then flip it down.
2. Fasten the Clip-on Bracket with the plastic screw.

## 3.4. Wiring

Three cables need to be connected to wire the system properly:

- Tool data cable between the tool(s) and the Compute Box
- Ethernet communication cable between the robot controller and the Compute Box

- Power supply of the Compute Box




**NOTE:**

For the Quick Changer - Robot Side no cable is needed to be connected.

### 3.4.1. Tool Data Cable

#### 3.4.1.1. Cable to 3FG15

First connect the data cable to the tool.



Use the M8-8pin connector on the Quick Changer or on the Dual Quick Changer.

Use the cable holder as illustrated on the left.



**CAUTION:**

Make sure to use the supplied cable holder to prevent any excessive strain on the 90-degree M8 connector caused by the rotation of the cable.

#### 3.4.1.2. Cable to Compute Box

Then route the Tool data cable to the Compute Box (CB) and use the supplied Velcro tape (black) to fix it.




**NOTE:**

Make sure that during the routing some extra length is used at the joints so that cable is not pulled when the robot moves.

Also make sure that the cable bending radius is minimum 40mm (for the HEX-E/H QC it is 70mm).

Finally, connect the other end of the Tool data cable to the Compute Box's DEVICES connector.



**CAUTION:**

Quick Changer and Dual Quick Changer can only be used to power OnRobot tools.

### 3.4.2. Ethernet Cable


Connect one end of the supplied Ethernet (UTP) cable to the robot controller's Ethernet (LAN) port.



**NOTE:**

If the robot controller's Ethernet port is in use, use a standard 4-port Ethernet switch to be able to use two network devices at the same time.

Connect the other end of the supplied cable to the Compute Box's ETHERNET connector.



**CAUTION:**

Use only shielded, maximum 3m long Ethernet cables.




**WARNING:**

Check and make sure that the Compute Box enclosure (metal) and the robot controller enclosure (metal) are not connected (no galvanic connection between the two).

### 3.4.3. Compute Box DIP Switch Settings

Set the DIP switches of the Compute Box as follows:




Set the DIP switch 3 to ON and the DIP switch 4 to OFF position.

For more information about the Ethernet interface settings, see [6.1.1. Ethernet Interface Setup](#).

### 3.4.4. Power Supply: Compute Box

Connect the supplied power supply to the Compute Box 24V connector.



**NOTE:**

To disconnect the power connector, make sure to pull the connector housing (where the arrows are shown) and not the cable.



**CAUTION:**

Use only original OnRobot power supplies.

Finally, power up the power supply that will power the Compute Box and the connected Tool(s).

#### 3.4.4.1. 3FG15

Power Supply	
1.5 A	✓
5 A	✓
6.25 A	✓


## 4. SW Installation


### 4.1. Robot Software Setup

#### 4.1.1. Import Component


OnRobot provides the component in one of the following ways:

1. The component is stored in the accompanying USB stick (OPTIONAL - may not be part of the delivery for some of the devices). Prepare the supplied OnRobot USB stick and plug it into the robot controller.
2. The component can be downloaded from [www.onrobot.com](http://www.onrobot.com). Copy the `TM_Export` folder to the root of an empty USB stick, then rename the USB stick to "TMROBOT". Plug the USB stick into the robot controller.


Click on the main menu  icon and go to  **System** menu.



Go to **Import/Export** and click **Import** (upper left corner). Then select your robot from the list and click **OK**.




Select the relevant OnRobot components to be added and click **Import**.




Go back to the main menu (☰) and go to **Settings**.






Click **Component** and make sure that all components are enabled that you would like to use.




### 4.1.2. Set Robot Network Settings

Go to the main menu (☰) and go to **Settings**.




Go to **Network** and setup the IP address of the robot.




It is recommended to use the factory default settings.

### 4.1.3. Configure Gripper Buttons

Go to the main menu (☰) and go to **Settings**.




Click on the **Gripper Button** and configure as shown below.




#### 4.1.4. Configuring Modbus TCP for the Components


You can open the `RG2_component_example` project or create a new project.

Add the `RGx_100_GRIP1` component from the left side. Note that not the full component name is shown only the `RGx_100`. You can use the icons to select the right action.


If you are not using the default Compute Box IP (192.168.1.1) then you need to set it. Click on the  icon on the right side of **Display** in the upper right corner.




Then click on **ModbusDev**. Select `Gripper_OR_RGx_100_Grip1_mtcp_RG2` and click on the Pencil icon.



Click on the pencil icon again in the upper right corner.



Make sure that the IP address is set correctly.



Repeat the same for the other Modbus device if needed.

Software setup is finished.

## 5. Operation



### NOTE:

It is assumed that the Installation has finished successfully. If not, first do the installation steps in the previous section.

### 5.1. Robot Operation Overview

You can use the previously installed OnRobot components to operate the OnRobot devices from the robot.



### NOTE:

OnRobot functions only accept input and returns output in metric units. If you have values to provide in US Standard units, use the following conversion rates.

US Standard unit	Metric unit	Convert US Standard unit into metric parameter input	Convert metric function output to US Standard unit
Linear measure (Length/Distance)			
1 inch (in or ")	25.4 millimetres	Multiply the US Standard input by 25.4 to get the metric unit input.	Divide the metric output by 25.4 to get the US Standard unit output.
1 foot (ft or')	0.304 metre	Multiply the US Standard input by 0.304 to get the metric unit input.	Divide the metric output by 0.304 to get the US Standard unit output.
Mass (Weight)			
1 pound (lb)	0.453 kilogram	Multiply the US Standard input by 0.453 to get the metric unit input.	Divide the metric output by 0.453 to get the US Standard unit output.
Torque			
1 lbft	1.355 Nm	Multiply the US Standard input by 1.355 to get the metric unit input.	Divide the metric output by 1.355 to get the US Standard unit output.

### Example


For example, `RGx_100_Grip1` is capable of opening and closing the gripper. The `RGx_100_Release1` is only added so that the Gripper Button can work as well.




**NOTE:**


The 100 in the component name corresponds to the actual component version (100=1.00).

You can change `Target width` and `Target force` variables by clicking on the arrow icon on the component.



To edit the value, click on the pencil icon.





**NOTE:**

The components with D1 and D2 prefix can be used only with Dual Quick Changer and the given device needs to be connected to 1 - primary or 2 - secondary side.

## 5.2. 3FG15 Components

### 5.2.1. Gripper\_OR\_3FG\_100\_GRIP

The gripping action has two phases:

- Move with low force close to the target diameter
- Move with target force to reach target diameter and engage mechanical lock

More information in the [7.1. Technical Sheets](#).

- **Target diameter:** Defines what the final diameter of the gripper should be. If this diameter is smaller than the workpiece diameter, the gripper will stop when it reaches the Target force. The diameter range is shown on the table below:

Finger Position	Fingertip (mm)	External Gripping range (mm)	Internal Gripping range (mm)
1	Ø10	10 - 117	35 - 135
	Ø13	7 - 114	38 - 138
	Ø16.5	4 - 111	41 - 140



Finger Position	Fingertip (mm)	External Gripping range (mm)	Internal Gripping range (mm)
2	Ø10	26 - 134	49 - 153
	Ø13	23 - 131	52 - 156
	Ø16.5	20 - 128	55 - 158
3	Ø10	44 - 152	65 - 172
	Ø13	41 - 149	68 - 174
	Ø16.5	38 - 146	71 - 176



**NOTE:**

To ensure a grip, set the target diameter as the workpiece diameter - 3 mm for an external grip and + 3 mm for an internal grip.

- **Target force:** Sets the target force in percentage 1-100, defining the closing speed and gripping force of the gripper when grabbing an object. The actual force can be found in the [7.1. Technical Sheets](#).
- **GripType:** Sets the gripping method to use.

Type	Method	Side view	Bottom view
0	Extern		
1	Intern		

The output has four gates:

- **ForceGripped:** Force grip detected; workpiece is gripped close to the target diameter; target force was detected and mechanical lock is engaged. Part was gripped with the expected force.
- **PartGripped:** Grip detected; target force was applied before reaching target diameter force is continually being applied mechanical lock is not engaged. Part grip detected early or gripper is obstructed.
- **NoGrip:** No grip detected; target diameter was reached without reaching target force. Nothing was gripped.

- `Error`: Gripper is in an error state.

### 5.2.2. Gripper\_OR\_3FG\_100\_RELEASE

Moves the gripper to a position with a low force without grip detection. If the gripper does not reach the target diameter within 5 seconds a timeout is triggered.

`TargetDiameter`: Sets the target diameter of the gripper in mm without fingertip offset

The output has two gates:

- `Success` - Target diameter was reached
- `Timeout` - Target diameter was not reached within 5 seconds

### 5.2.3. Gripper\_OR\_3FG\_100\_CONFIG

Configuration component for 3FG, allowing changes to fingertip diameter, finger position and finger length. This is typically done once on program initialization.

See more information in [7.1. Technical Sheets](#).

- `FingertipDiameter`: Sets the fingertip diameter of the 3FG gripper in [mm] - default: 10.0
- `FingerPosition`: Sets the finger position of the 3FG gripper, [1-3] matching hole markings on underside of the gripper.
- `FingerLength`: Sets the arm length of the 3FG gripper in [mm]; This parameter should only be modified if using custom fingers - default: 49.0

The output has two gates:

- `Success`: Configuration was successfully updated
- `Fail`: Failed to update configuration

## 6. Additional Software Options

### 6.1. Compute Box/Eye Box

#### 6.1.1. Ethernet Interface Setup

A proper IP address must be set for the Compute Box/Eye Box and the robot/computer to be able to use the Ethernet interface. The IP address can be configured using DIP switches 3 and 4.



**WARNING:**

Stop the robot program before you change any Ethernet interface settings.



**NOTE:**

Configuring DIP switch 3 will remove any previously set static IP address.

To change between modes, first change the DIP switches and then cycle the Compute Box/Eye Box power so the changes will take effect.

**DIP 3** - sets the Compute Box / Eye Box IP address

- **ON:** Fixed IP (192.168.1.1)
- **OFF:** Dynamic or Static IP (*can be configured via the Web Client*)


**DIP 4** - sets whether the connected robot or laptop will receive IP address from the Compute Box / Eye Box

- **ON:** DHCP server is disabled
- **OFF:** DHCP server is enabled

We recommend to set the DIP switches according to either of the two options below:

- **Fix IP/Auto mode** - in simple installations (no external network and/or no PLC connected)
- **Advanced mode** - in more complex installations (external network and/or PLC are used)

#### Fix IP/Auto mode (factory default)




Set the DIP switch 3 to ON and the DIP switch 4 to OFF position and cycle the power so the changes will take effect.

IP Address of the Compute Box/Eye Box	IP Address of the Robot/Computer
<p>The IP address of the Compute Box/Eye Box is fixed 192.168.1.1. This IP address cannot be changed.</p>	<p>The Compute Box/Eye Box will automatically assign an IP address to the connected robot/computer if it was configured to obtain an IP address automatically.</p> <div data-bbox="719 524 815 613" style="display: inline-block; vertical-align: middle;"> </div> <p><b>NOTE:</b> The assigned IP address range is 192.168.1.100-105 (with subnet mask 255.255.255.0). If the Compute Box/Eye Box is used in a company network where a DHCP server is already in use, it is recommended to use Advanced mode.</p>

In this mode, the DHCP server of the Compute Box/Eye Box is enabled.

**Advanced mode (any static or dynamic IP/subnet mask)**



Set the DIP switch 3 to OFF and the DIP switch 4 to ON position and cycle the power so the changes will take effect.

IP Address of the Compute Box/Eye box	IP Address of the Robot/Computer
<p><b>Case 1:</b> Static IP address The IP address 192.168.1.1 is already in use in your network or a different subnet needs to be configured.</p>	<p>The Compute Box/Eye Box will not assign an IP address to the robot/computer. Set the IP address of the robot/computer manually. Make sure to have a matching IP setting to your robot/computer network for a proper communication. Use the same subnet but different IP address.</p>
<p><b>Case 2:</b> Dynamic IP address *</p>	<p>The IP address of the robot/computer is set dynamically. An external DHCP server assigns the IP address to the robot/computer.</p>

\* By default, the IP address of the Compute Box/Eye Box is set to Dynamic IP.

The IP address of the Compute Box/Eye Box can be set to any value by using the Web Client. For more details, see section Web Client: Configuration Menu. Under **Network settings**, set the **Network mode** to either **Static IP** or **Dynamic IP**.

In this mode, the DHCP server of the Compute Box/Eye Box is disabled.


## 6.1.2. Web Client

To access the Web Client on your computer first the Ethernet interface needs to be set up to have a proper communication between your computer and the Compute Box. It is recommended to use the factory default DIP switch settings (DIP 3 On and DIP 4 Off) (for further details see section [6.1.1. Ethernet Interface Setup](#)).

Then do the following steps:

- Connect the Compute Box to your computer with the supplied UTP cable.
- Power the Compute Box with the supplied power supply
- Wait one minute for the Compute Box LED to turn from blue to green.
- Open a web browser on your computer and type in the IP address of the Compute Box (factory default is 192.168.1.1).

The Sign-in page opens:



Sign in to OnRobot  
Web Client

USERNAME  
admin

PASSWORD  
●●●●●●

Remember me

[Forgot your password?](#)

Please sign in with the 'admin' username and the default password.  
You will be prompted to change the default password at first login.

The factory default administrator login is:

**Username:** admin

**Password:** OnRobot

For the first login a new password needs to be entered: (password must be at least 8 characters long)

## Change the default administrator password

**NEW PASSWORD**

**CONFIRM PASSWORD**

Once signed in the following top menus appear:






- **Devices** - Monitor and control the connected devices (e.g.: grippers)
- **Configuration** - Change the Compute Box's settings
- **WebLogic™** - Program the Digital I/O interface through OnRobot WebLogic™
- **Paths** - Import/export the recorded Paths (not available to all robots)
- **Update** - Update the Compute Box and the devices
- Account settings (e.g.: change password, add new user)
- Select the language of the Web Client

In the following, these menus will be described.

### 6.1.3. Web Client: Devices Menu

To control/monitor a device click on the **Select** button.

Please select from the detected device(s):

 <p>Compute Box</p> <p><input type="button" value="SELECT"/></p>	 <p>HEX-E/H QC</p> <p><input type="button" value="SELECT"/></p>	 <p>RG2</p> <p><input type="button" value="SELECT"/></p>
---	--	---

### 6.1.3.1. 3FG15

#### 3FG15

This page allows the device to be monitored and controlled. By navigating to the Device info tab the device status is shown. (Some functions might not be accessible without Admin permission.)

Monitor and control
Settings
Device info

---

#### States

- Busy
- Grip detected
- Force grip detected

---

#### Move

**TARGET RAW DIAMETER**

86 mm

Current raw diameter: 85.7 mm

---

#### Grip

- External grip
- Internal grip

Current calculated target: 69.2 mm

**TARGET DIAMETER:**  mm

**TARGET FORCE:**  %

The state of the gripper could be:

- **Busy** - the gripper is in motion
- **Grip detected** - the gripper has detected a workpiece
- **Force grip detected** - the gripper has applied the target force to a workpiece. This also activates a break. See more info in section [Finger Movement and Force](#).

The gripper can be controlled in two modes:

- **Move** mode - The easiest way to move the gripper but the gripping force is limited (<50N). This should be used to release a part and open the gripper.
- **Grip** mode - This should be used to properly grip a part with a given target force. If the part is properly gripped (target force is reached) the break will engage to make sure the part will not be dropped in case of a power loss.

In **Move** mode:

The gripper can be controlled by adjusting the **Target raw diameter** slider. The actual values of the fingers are shown by the **Current raw diameter**. The raw diameter is without the fingertip offset.

In **Grip** mode:

First set how to grip the part:

- Externally or
- Internally

To grip on a part set the **Target diameter** and **Target force** and click on the **Grip** button.

There are two ways how the target diameter can be given:

- Enter manually - make sure to add 3mm to the part diameter if it is gripped internally and subtract 3mm if it is gripped externally
- Use the **Calculate target** button:

Move the fingers with the slider to touch the part and activate the **Grip detected** (open fully for an internal grip or close fully for an external grip).

Based on whether it will be external or internal the **Current calculated target** (diameter) for the grip is shown. The fingertip offset is either added or subtracted to compensate for the set fingertip.

Grip type	Current calculated target value
External grip	Current raw diameter - Fingertip offset - 3 mm
Internal grip	Current raw diameter + Fingertip offset + 3 mm

Click on the **Calculate target** button to load the calculated value to the **Target diameter**.

If the grip was successful, the **Force grip detected** signal should be activated and the engaged brake should make a clicking sound.

During the gripping the motion of the finger can be terminated by clicking on the **Stop** button.

To release the part from a gripped status, move the gripper:

- Outward in case of an external grip
- Inward in case of an internal grip.

The default finger setting can be changed on the **Settings** tab:



### 3FG15

This page allows the device to be monitored and controlled. By navigating to the Device info tab the device status is shown. (Some functions might not be accessible without Admin permission.)

Monitor and control   **Settings**   Device info

#### Select finger position




SAVE

#### Set finger length

Override standard (49 mm)

49 mm



SAVE

#### Set fingertip offset

- Ø 10 Steel
- Ø 13 Steel
- Ø 13.5 Silicone
- Ø 16.5 Silicone
- Custom



13.5 mm

SAVE

- **Select finger position** - Select the mounted finger position and **Save**.
- **Set finger length** - If customized fingers are needed, the checkbox can be enabled, and the new finger length can be entered.
- **Set fingertip offset** - The 4 different types that are delivered with the gripper can be selected by pressing the radio button. If customized fingertips are made, the custom option can be selected.

Saving any of these 3 settings will automatically apply the changes. Different finger positions, fingertip diameters and finger lengths will allow to achieve different diameters and forces. Find more information in sections [Gripping Force](#) and [Gripping Diameter](#).

### 6.1.4. Web Client: Configuration Menu

#### Configuration

This page allows the configuration of the Compute Box.

**CAUTION**  
 Incorrect settings may cause the device to lose network connectivity.

1. Digital input mode: NPN
2. Digital output mode: NPN
3. Compute Box IP setting is configured on this page.
4. DHCP server enabled: Compute Box tries to assign IP to the robot.

#### NETWORK SETTINGS

MAC address	b8:27:eb:0e:c9:a3
Network mode	Static IP <span style="float: right;">⌵</span>
IP address	192.168.1.1 <span style="float: right;">✎</span>
Subnet mask	255.255.255.0 <span style="float: right;">✎</span>

SAVE

#### ETHERNET/IP SCANNER SETTINGS

IP address to connect to	---
Origin-to-target instance id	1
Target-to-origin instance id	1
Configuration instance id	0
Requested packet interval (ms)	8

SAVE

#### COMPUTE BOX SETTINGS

Display name

✎

SAVE

Clock delay

⚠

SYNCHRONIZE CLOCK

**Network settings:**

The **MAC address** is a world-wide unique identifier that is fixed for the device.

The **Network mode** drop-down menu can be used to decide if the Compute Box will have a static or a dynamic IP address:

- If it is set to **Dynamic IP**, the Compute Box expects an IP address from a DHCP server. If the network that the device is connected to has no DHCP server, the Compute Box will not obtain an IP address and its LED is lighting in blue.
- If it is set to **Static IP**, then a fixed IP address and subnet mask must be set.
- If it is set to **Default Static IP**, the fixed IP revert to the factory default and cannot be changed.

After all parameters are set, click on the **Save** button to store the new values permanently. Wait 1 minute and reconnect to the device using the new settings.

#### **Compute Box / Eye Box settings:**

In case, more than one Compute Box is used within the same network, for identification purpose any user specific name can be entered to the **Display name**.

If the **Clock delay** field shows a difference, click **Synchronize clock** to synchronize the Compute Box's time with your computer.

#### **EtherNet/IP scanner settings:**



#### **NOTE:**

This is a special option of the EtherNet/IP connection for some robots.

In case when the robot is the Adapter and the Compute Box needs to be the Scanner the following addition information is required for the communication:

- **IP address to connect to** - the robot IP address
- **Origin-to-target instance id** - refer to the robot's EtherNet/IP manual (Scanner mode)
- **Target-to-origin instance id** - refer to the robot's EtherNet/IP manual (Scanner mode)
- **Configuration instance id** - refer to the robot's EtherNet/IP manual (Scanner mode)
- **Requested packet interval (ms)** - RPI value in ms (minimum 4)

Check the checkbox and the Compute Box will try to automatically connect to the robot (via the given IP address).

### **6.1.5. Web Client: Update Menu**

This page can be used to update the software on the Compute Box and the firmware on the devices.

### Update

This page allows updating the software and firmware.

**CAUTION**  
Installing updates may take several minutes to complete. Please do not power off or unplug your Compute Box or any of the connected devices during the update process.

**SOFTWARE**

No update file selected yet...

BROWSE

[Click here to download the result of the last update.](#)

**FIRMWARE**

COMPONENTS	CURRENT VERSION	REQUIRED VERSION	
<b>Compute Box (CBOX_RPT)</b>			
Firmware	150	150	✓
<b>HEX-E/H QC (HEXHC001)</b>			
Firmware	208	208	✓

UPDATE

✓ Up-to-date   
 ↻ Update required   
 ✗ Downgrade not supported



**CAUTION:**

During the update process (takes about 5-10 minutes) DO NOT unplug any device or close the browser window. Otherwise the updated device could be damaged.

The loading screens during the update process are the same for the software and the firmware updates.

**Software Update**

Start the software update by clicking on the **Browse** button to browse for the .cbu software update file.

Then the **Browse** button will turn to **Update**.

Click on that **Update** button to start the software update process, see below.



If the update is finished and was successful, the message below is shown.

**Firmware Update**

The firmware update is only required when any of the components is out of date.

To start the firmware update, click on **Update** button in the firmware section of the page, see below.


If the update is finished and was successful, the message below is shown.



### 6.1.6. Web Client: Account Settings

This menu can be used to:

- See the currently sign-id user
- Go to **Account settings**
- Sign-out




#### Account settings:


This page has two tabs:

- **My profile** - to see and update the currently logged in users' profile (e.g.: change password)
- **Users** - to manage users (e.g.: add/remove/edit)

On the **My profile** tab to change any profile data (e.g.: password) click on the **Update profile** button.



On the **Users** tab click on the **Add new user** button to add more users:



**Add new user** [X]

**USERNAME**  
Enter username here

**FIRST NAME**

**LAST NAME**

**E-MAIL**

**PHONE**

**ROLE** [User] [v]      **STATUS**  Active

**DESCRIPTION**

**PASSWORD**  
Enter user's password here


**CONFIRM PASSWORD**  
Re-enter password here


[SAVE] [CANCEL]

There are three user levels:


- Administrator
- Operator
- User

Fill in the user information and click **Save**.

Later on to change any user information just click on the edit  icon.



To prevent a user to sign-in either could be:





- deactivated by changing its **Active** status in the edit mode
- or removed by clicking the delete  icon.



## 7. Hardware Specification

### 7.1. Technical Sheets

#### 7.1.1. 3FG15

General Properties		Minimum	Typical	Maximum	Unit
Payload Force Fit		-	-	10	[kg]
		-	-	22	[lb]
Payload Form Fit		-	-	15	[kg]
		-	-	33	[lb]
Grip Diameter*	External 	4 0.16	- -	152 5.98	[mm] [inch]
	Internal 	35 1.38	- -	176 6.93	[mm] [inch]
Finger position resolution		-	0.1	-	[mm]
		-	0.004	-	[inch]
Diameter repetition accuracy		-	0.1	0.2	[mm]
		-	0.004	0.007	[inch]
Gripping force		10	-	240	[N]
Gripping force (adjustable)		1	-	100	[%]
Gripping speed (diameter change)		-	-	125	[mm/s]
Gripping time (including brake activation)**		-	500	-	[ms]
Hold workpiece if power loss?		Yes			
Storage temperature		0	-	60	[°C]
		32	-	122	[°F]
Motor	Integrated, electric BLDC				
IP Classification	IP67				
Dimensions [L, W, Ø]	156 x 158 x 180				[mm]
	6.14 x 6.22 x 7.08				[inch]
Weight	1.15				[kg]
	2.5				[lb]

\* With the scope of delivery


\*\* 10 mm diameter distance. Also see section [Finger Movement and Force](#)

Operating Conditions	Minimum	Typical	Maximum	Unit
Power supply	20	24	25	[V]
Current consumption	43	-	1500*	[mA]
Operating temperature	5	-	50	[°C]
	41	-	122	[°F]
Relative humidity (non-condensing)	0	-	95	[%]
Calculated MTBF (operating life)	30.000	-	95	[Hours]


\*600 mA set as default.

### Fingers

The supplied fingers can be mounted in 3 different positions to achieve different **Gripping Forces** and different **Gripping Diameters**.



The delivered finger length is 49 mm (L in the drawing below). If custom fingers are required, they can be made to fit the Gripper according to the dimensions (mm)[inch] shown below. The needed screws are M4x8mm (use 3 Nm tightening torque):




### Fingertips


The supplied fingertips are listed below. Different fingertips will allow to achieve different **Gripping Forces** and different **Gripping Diameters**.

- $\varnothing 10$  mm steel
- $\varnothing 13$  mm steel
- $\varnothing 13.5$  mm silicone
- $\varnothing 16.5$  mm silicone


If custom fingertips are required, they can be made to fit the Gripper's fingers according to the dimensions (mm)[inch] shown below. The needed screws are M4x8mm:



In the graph below, the maximum payload allowed for customized fingertip given a length is shown.




In the graph below, how the % of maximum achievable force decreases as the finger length increases when customized fingertips are used.



### X-shape fingertips

These fingertips improve the gripper's ability to pick and place round workpieces with collar like features. By combining the force fit and the form fit gripping approaches, the fingertips increase the stability and payload of the workpiece to be gripped.




When these fingertips are used, set the fingertip diameter to 16 mm in the robot program. These fingertips are optional accessories and need to be purchased separately. To purchase these fingertips, please contact the distributor.

- 3FG X-Shape fingertips PN 105877

### Types of Grips


In the document the internal and external grip terms are used. These grips are related to how the workpiece is gripped.




### Gripping Force

The total gripping force highly depends on the finger angle  $\theta$ . For both internal and external grip, the lower the finger angle, the higher the force that will be applied as shown in the graph below.

Although the fingers can move from 0 to 180, the angle range of an external grip is 30°-165° and for an internal grip 20°-160°



Maximum Force and Finger Angle  $\theta$



Graph plotted using measurements with 1 A current, silicone fingertips and a metal workpiece.



**NOTE:**

The total force applied depends on the finger angle, the input current (limited in some robots' tool flange connection) and the friction coefficient between the materials of the fingertips and the workpiece.

### Finger Movement and Force

The gripping action has two phases:

Phase 1: For a safety reason, the fingers will start moving with a low force (maximum ~50 N) to avoid damaging anything that could get clamped between the gripper fingers and the workpiece.

Phase 2: When the gripper diameter is very close to the programmed target diameter, the gripper will increase the force to grip with the programmed target force. After the grip, a break will be activated (tic sound). The activation of the brake, also known as, Force grip detected, can be verified in the GUI. This brake will hold the workpiece with the applied force, with no power consumption and holding the workpiece in case of power loss. This brake will automatically be deactivated when the gripper performs a release or a new grip command. While programming the gripper, the brake can be deactivated by using the features in the GUI.

### Gripping Diameter

The different configurations of the delivered finger and fingertips allow to achieve a wide range of diameters.

Finger Position	Fingertip (mm)	External Gripping range (mm)	Internal Gripping range (mm)
1	Ø10	10 - 117	35 - 135
	Ø13	7 - 114	38 - 138
	Ø16.5	4 - 111	41 - 140
2	Ø10	26 - 134	49 - 153
	Ø13	23 - 131	52 - 156
	Ø16.5	20 - 128	55 - 158
3	Ø10	44 - 152	65 - 172
	Ø13	41 - 149	68 - 174
	Ø16.5	38 - 146	71 - 176

Based on:

- Angle for external gripping min 165° (Pos 1), 163 ° (Pos 2), 161 ° (Pos 3) and max 30° (all 3 positions)
- Angle for internal gripping min 160° and max 30°

The closer to the maximum diameter range, the lower the angle and, therefore, the higher the force.

## 7.1.2. Compute Box

### 7.1.2.1. With 1.5A Wall Adapter (36W)

Supplied Wall Adapter	Minimum	Typical	Maximum	Unit
Input voltage (AC)	100	-	240	[V]
Input current	-	-	1	[A]
Output voltage	-	24	-	[V]
Output current	-	1.5	-	[A]

Compute Box Power input (24V connector)	Minimum	Typical	Maximum	Unit
Supply voltage	-	24	25	[V]
Supply current	-	1.5	-	[A]

Compute Box Power output (Device connector)	Minimum	Typical	Maximum	Unit
Output voltage	-	24	25	[V]
Output current	-	1.5	-	[A]

### 7.1.2.2. With 6.25A Wall Adapter (150W)

Supplied Wall Adapter	Minimum	Typical	Maximum	Unit
Input voltage (AC)	100	-	240	[V]
Input current	-	-	2.1	[A]
Output voltage	-	24	-	[V]
Output current	-	6.25	-	[A]

Compute Box Power input (24V connector)	Minimum	Typical	Maximum	Unit
Supply voltage	-	24	25	[V]
Supply current	-	6.25	-	[A]

Compute Box Power output (Device connector)	Minimum	Typical	Maximum	Unit
Output voltage	-	24	25	[V]
Output current	-	4.5	4.5*	[A]

\* Peak currents

### 7.1.2.3. Compute Box I/O interface

Power Reference (24V, GND)	Minimum	Typical	Maximum	Unit
Reference output voltage	-	24	25	[V]
Reference output current	-	-	100	[mA]

Output (DO1-DO8)	Minimum	Typical	Maximum	Unit
Output current - altogether	-	-	100	[mA]
Output resistance (active state)	-	24	-	[Ω]

Input (DI1-DI8) as PNP	Minimum	Typical	Maximum	Unit
Voltage level - TRUE	18	24	30	[V]
Voltage level - FALSE	-0.5	0	2.5	[V]





Input (DI1-DI8) as PNP	Minimum	Typical	Maximum	Unit
Input current	-	-	6	[mA]
Input resistance	-	5	-	[kΩ]

Input (DI1-DI8) as NPN	Minimum	Typical	Maximum	Unit
Voltage level - TRUE	-0.5	0	5	[V]
Voltage level - FALSE	18	24	30	[V]
Input current	-	-	6	[mA]
Input resistance	-	5	-	[kΩ]

## 7.2. Mechanical Drawings

### 7.2.1. Mountings

#### 7.2.1.1. Quick Changer - Robot Side



\* Distance from Robot flange interface to OnRobot tool.  
 All dimensions are in mm and [inches].





**NOTE:**

The cable holder (on the left side) is only required with the long (5 meter) cable.

**7.2.2. Tools**

**7.2.2.1. 3FG15**









All dimensions are in mm and [inches].

### 7.2.2.2. Compute Box

#### Compute Box



### Clip-on Bracket (optional)



All dimensions are in mm and [inches].

## 7.3. COG, TCP

COG, TCP, and weight parameters of the single devices (without any mounting/adapter):

### 7.3.1. 3FG15

Coordinate system	TCP [mm]	Center of Gravity [mm]	Weight
	<p>X=0</p> <p>Y=0</p> <p>Z=156</p>	<p>cX=0</p> <p>cY=0</p> <p>cZ=83</p>	<p>1.15 kg</p> <p>2.5 lb</p>

\* With delivered fingers and 13.5 silicone fingertips on.

Use the TCP/COG Calculator to calculate the TCP and COG values for your OnRobot product combination.

The TCP/COG Calculator can be downloaded from [www.onrobot.com/downloads](http://www.onrobot.com/downloads).

## 8. Maintenance

**WARNING:**

An overall inspection of the OnRobot's End of Arm Tooling must be performed regularly and at least once every 6 months. This inspection must include but is not limited to check for defective material and clean gripping surfaces.

Use original spare parts, and original service instructions for the OnRobot's End of Arm Tooling and the robot. Failure to comply with this precaution can cause unexpected risks, resulting in severe injury.

If you have questions regarding spare parts and repair, please visit our website [www.onrobot.com](http://www.onrobot.com) to contact us.

### 8.1. 3FG15

---

**WARNING:**

Please check regularly the silicon fingertips since these parts can wear out.

If the fingertip is worn out , it can be ordered as spare part:

- Ø10 mm steel, PN 104160
- Ø13 mm steel, PN 104241
- Ø13.5 mm silicone, PN 104162
- Ø16.5 mm silicone, PN 104240

## 9. Troubleshooting

### 9.1. Robot Has Not Obtained an IP Address

---

If the Compute Box has not assigned an IP address to the robot, do the following:

Assign a static IP address to the robot that matches your current IP settings on your Compute Box. The default IP address of the Compute Box is 192.168.1.1.



**NOTE:**

Change the last number in the IP address (if using 255.255.255.0 subnet mask) to avoid an IP conflict with the Compute Box.

#### Example

If the default fixed (192.168.1.1) IP address is used on the Compute Box, then use the following values:

- IP address: 192.168.1.2
- Subnet Mask: 255.255.255.0

### 9.2. Error During Operation

---

If an error occurs during operation, try the following:

1. Restart the robot and check the functionality.
2. If the error is still present, contact the distributor from where the product has been purchased.

## 10. Warranties

### 10.1. Patents

---

Products of OnRobot A/S are protected by several patents; some still in global publication process (Patents pending). All manufacturers of copies and similar products violating any patent claims will be prosecuted.

### 10.2. Product Warranty

---

Without prejudice to any claim the user (customer) may have in relation to the dealer or retailer, the customer shall be granted a manufacturer's warranty under the conditions set out below:

In the case of new devices and their components exhibiting defects resulting from manufacturing and/or material faults within 12 months of entry into service (maximum of 15 months from shipment), OnRobot A/S shall provide the necessary spare parts, while the customer (user) shall provide working hours to replace the spare parts, either replace the part with another part reflecting the current state of the art, or repair the said part. This warranty shall be invalid if the device defect is attributable to improper treatment and/or failure to comply with information contained in the user guides. This warranty shall not apply to or extend to services performed by the authorized dealer or the customer themselves (e.g. installation, configuration, software downloads). The purchase receipt, together with the date of purchase, shall be required as evidence for invoking the warranty. Claims under the warranty must be submitted within two months of the warranty default becoming evident. Ownership of devices or components replaced by and returned to OnRobot A/S shall vest in OnRobot A/S. Any other claims resulting out of or in connection with the device shall be excluded from this warranty. Nothing in this warranty shall attempt to limit or exclude a customer's statutory rights nor the manufacturer's liability for death or personal injury resulting from its negligence. The duration of the warranty shall not be extended by services rendered under the terms of the warranty. Insofar as no warranty default exists, OnRobot A/S reserves the right to charge the customer for replacement or repair. The above provisions do not imply a change in the burden of proof to the detriment of the customer. In case of a device exhibiting defects, OnRobot A/S shall not be liable for any indirect, incidental, special or consequential damages, including but not limited to, lost profits, loss of use, loss of production or damage to other production equipment.

In case of a device exhibiting defects, OnRobot A/S shall not cover any consequential damage or loss, such as loss of production or damage to other production equipment.

### 10.3. Disclaimer

---

OnRobot A/S continues to improve reliability and performance of its products, and therefore reserves the right to upgrade the product without prior warning. OnRobot A/S ensures that the content of this manual is precise and correct but takes no responsibility for any errors or missing information.

# 11. Certifications



This is to certify that the management system of:

## OnRobot A/S

Main Site: Teglværksvej 47 H, 5220 Odense SØ, Denmark  
 Chamber of Commerce: 36492449  
 Additional Site: OnRobot A/S, Cikorievej 44, 5220 Odense SØ, Denmark

has been registered by Intertek as conforming to the requirements of

## ISO 9001:2015

The management system is applicable to:

Development and sales of End-of-Arms tools for industrial customers worldwide.

**Certificate Number:**  
0096721

**Initial Certification Date:**  
26 November 2019

**Date of Certification Decision:**  
26 November 2019

**Issuing Date:**  
26 November 2019

**Valid Until:**  
25 November 2022



**Intertek**

**Carl-Johan von Plomgren**  
MD, Business Assurance Nordics

Intertek Certification AB  
 P.O. Box 1103, SE-164 22 Kista, Sweden



In the issuance of this certificate, Intertek assumes no liability to any party other than to the Client, and then only in accordance with the agreed upon Certification Agreement. This certificate's validity is subject to the organization maintaining their system in accordance with Intertek's requirements for systems certification. Validity may be confirmed via email at [certificate.validation@intertek.com](mailto:certificate.validation@intertek.com) or by scanning the code to the right with a smartphone. The certificate remains the property of Intertek, to whom it must be returned upon request.



## 11.1. EMC



### Attestation of Conformity no. 120-33441-A1

FORCE Technology has performed compliance testing on electrical products since 1967. FORCE Technology is an accredited test house according to EN17025 and participates in international standardization with organizations such as CEN/CENELEC, IEC/CISPR and ETSI. This attestation of conformity with the below mentioned standards and/or normative documents is based on accredited tests and/or technical assessments carried out at FORCE Technology.

<b>Attestation holder</b> OnRobot A/S Teglværksvej 47H 5220 Odense SØ Denmark	
<b>Product identification - Name (Part no.)</b> <b>Power Supplies:</b> PSU (104788), VER36U240-JA, VES120PS24, VES150PS24. <b>Controllers:</b> UR Kit with Compute Box (102344), Doosan Robot kit (102345), Techman/OMRON TM Robot Kit (102359), KUKA-A Robot kit (102360), KUKA-B Robot kit (102361), FANUC Robot kit (102362), Kawasaki-B Robot kit (102363), Kawasaki-C Robot kit (102364), Kawasaki-D Robot kit (102365), Kawasaki-E Robot kit (102366), Yaskawa-F Robot kit (102367), Yaskawa-G Robot kit (102368), Yaskawa-H Robot kit (102369), NACHI-I Robot kit (102370), NACHI-J Robot kit (102371), Hanwha Robot Kit (103208), Eye Box (103707). <b>Mountings:</b> Dual Quick Changer (101788), Quick Changer Robot side (102037), HEX-E QC (102111), Quick Changer Kit (102277), HEX-H QC (102376), Quick Changer Robot side 4,5A (104277), Dual Quick Changer 4,5A (104293), Quick Changer Kit 4,5A (104388). <b>Tools:</b> 2FG7 (106376), 3FG15 (103666), MG10 (105202), OnRobot Eyes (103903), RG2 (102012), RG2-FT (102075), RG6 (102021), Sander (106376), Screwdriver (103961), SG Base Part (103546), VG10 (101661), VGC10 (102844), VGP20 (107242).	
<b>Manufacturer</b> OnRobot A/S	
<b>Technical documentation</b> Assessment no. 120-33441-A1	
<b>Standards/Normative documents</b> IEC 61000-3-2:2018 IEC 61000-3-3:2013/AMD1:2017 IEC 61000-6-2:2016 IEC 61000-6-4:2018 EMC Directive 2014/30/EU, Article 6 EN 61000-3-2:2014 EN IEC 61000-3-2:2019 EN 61000-3-3:2013/A1:2019 EN 61000-6-2:2005/AC:2005 EN IEC 61000-6-2:2019 EN 61000-6-4:2007/A1:2011 EN IEC 61000-6-4:2019 Additionally, for RG2 (102012) and RG6 (102021): IEC 61326-3-1:2017, Industry locations, SIL 2 The product identified above has been assessed and complies with the specified standards/normative documents. The attestation does not include any market surveillance. It is the responsibility of the manufacturer that mass-produced apparatus have the same properties and quality. This attestation does not contain any statements pertaining to the requirements pursuant to other standards, directives or laws other than the above mentioned.	
<b>Signature</b> 	Digitally signed by Knud A. Baltsen Date: 2021.03.02 16:14:10 +01'00'
Signed by: Knud A. Baltsen, Senior Specialist, Product Compliance	



FORCE Technology  
 Venlighedsvej 4  
 2970 Hørsholm, Denmark  
 +45 43 25 14 00  
 +45 43 25 00 10  
 info@forcetechnology.dk

FORCE Technology Norway AS  
 Nye Vakkås vei 32  
 1395 Hvalstad, Norway  
 +47 64 00 35 00  
 +47 64 00 35 01  
 info@forcetechnology.no

FORCE Technology  
 Park Allé 345  
 2605 Brøndby, Denmark  
 +45 43 25 00 00  
 +45 43 25 00 10  
 info@forcetechnology.dk

## 11.2. Declaration of Incorporation

---

### 11.2.1. 3FG15

#### CE/EU Declaration of Incorporation (Original)

According to European Machinery Directive 2006/42/EC annex II 1.B.

The manufacturer:

OnRobot A/S  
 Teglværskvej 47H  
 DK-5220, Odense SØ  
 DENMARK

declares that the product:

Type: Industrial Robot Gripper  
 Model: 3FG15  
 Generation: V1  
 Serial: 1000000000-1009999999

may not be put into service before the machinery in which it will be incorporated is declared in conformity with the provisions of Directive 2006/42/EC, including amendments, and with the regulations transposing it into national law.

The product is prepared for compliance with all essential requirements of Directive 2006/42/EC under the correct incorporation conditions, see instructions and guidance in this manual. The following essential requirements of Directive 2006/42/EC are fulfilled: 1.1.2, 1.1.3, 1.1.5, 1.3.2, 1.3.4, 1.5.1, 1.5.2, 1.5.4, 1.5.5, 1.5.10, 1.5.11, 1.5.12, 1.6.1. Compliance with all essential requirements of Directive 2006/42/EC relies on the specific robot installation and the final risk assessment.

Technical documentation is compiled according to Directive 2006/42/EC annex VII part B and available in electronic form to national authorities upon legitimate request. Undersigned is based on the manufacturer address and authorized to compile this documentation.

Additionally, the product declares in conformity with the following directives, according to which the product is CE marked:

2014/30/EU — Electromagnetic Compatibility Directive (EMC)  
 2011/65/EU — Restriction of the use of certain hazardous substances (RoHS)


Relevant essential health and safety requirements of the following EU directives are also applied:

2014/35/EU — Low Voltage Directive (LVD)  
 2012/19/EU — Waste of Electrical and Electronic Equipment (WEEE)

A list of applied harmonized standards, including associated specifications, is provided in this manual.

Budapest, November 11th, 2020

Group Management

  
 Vilmos Beskid  
 CTO